




## Koman pou byen enstale prela epi prekosyon pou pran avèl.



Pa klouwe prela avek klou senp Pa pike prela a nan tè a.



Klouwe l avèk klou tòl oubyen bouchon kola o sinon yon moso bwa.



Mete wòch antrel sou tout longè prela a oubyen mete yon wòch nan pwent prela a marel ak yon fil epi pikel nan tè a.




Mal

Pa pèse prela nan pati fin an



Bien



Bien

Bien


pèse prela nan zòn pwès la.

Vlope yon wòch nan pwent prela a marel ak yon fil epi pikel nan tè a o sinon marel nan yon poto.

## Bay tèt kay la pant et byen detirel prela sou li.




Mal



Bien

Bal pant e byen detirel pou dlo pa dòmi sou prela a. (poul pa fè basen).

## Pou pa mete dife nan tant lan



pa limen dife pou w fè manje anndan tant la.



Pa limen balèn andedan tant lan konsa, metel pito nan yon bokal epi pa kite balèn n la limen pandan wap dòmi.